

# KitchenAid Stand Mixer Optional Accessory

## Maximum Extraction slow Juicer and Sauce Attachment 5KSM1JA



- **Two-stage slow juicing technology with stainless steel pre-slicing blade and auger assembly**  
For maximum extraction of juice with less prep work and less foam
- **2-in-1 extra wide feed tube with hopper**  
Accommodates various sizes of soft, hard or leafy fruits and vegetables while reducing pre-cutting
- **Three pulp screens: low pulp, high pulp and saucing/jams**  
Choice of pulp preference for a wide variety of foods like smooth herb and vegetable juices, savoury coulis, thick fruit purées, and sweet jams
- **Conveniently attaches to the stand mixer with a compact design**  
Discover endless possibilities for everyday use, with easy storage
- **Drip stop control**  
Control the juice flow in between servings

# KitchenAid Stand Mixer Optional Accessory

## Maximum Extraction slow Juicer and Sauce Attachment 5KSM1JA\*

### TECHNICAL DATA

Colour	Silver		
Material body	Tritan/ABS		
Material juicing bowl	BPA-free ultimate crystal plastic		
Product dimensions	H x W x D	29.5 x 17.8 x 24.6 cm	
Packaging dimensions	H x W x D	23.9 x 33.8 x 32.3 cm	
Master pack dimensions	H x W x D	24.9 x 65.3 x 34.8 cm	
Net weight (all acc included)	3.3 kg		
Net weight	2.2 kg		
Gross weight	3.8 kg		
Master pack gross weight	8.2 kg		
Master pack	2 units		
Country of origin	China		

REFERENCE	DESCRIPTION	EAN	EAN Master pack (2 units)
5KSM1JA	Juicer Attachment	5413184000745	5413184000752

### STANDARD ACCESSORIES



**2-in-1 wide feed tube and dual food pushers**  
For a wide variety of fruits and vegetables.



**Auger/blade assembly**  
Includes a stainless steel slicing blade.  
To place inside one of the screens.  
Plastic auger and polished stainless steel blade.



**BPA-free juicing bowl**  
To fit the different screens.



**Screen/juicing bowl wiper basket**  
Wipes the screen non-stop in juicing bowl while in use to produce juice without clogging.  
Red wiper blades are made out of flexible rubber.



**Pulp container**  
To place under the pulp ejector/chute.



**Screen low pulp**  
Leaves less pulp for a smoother juice.  
Made out of polished stainless steel.



**Screen high pulp**  
Leaves more pulp for a thicker juice.  
Made out of polished stainless steel.



**Screen saucing/jams**  
To make sauces and jams.  
Made out of polished stainless steel.



**1 L juice container**  
To place under the juice spout.



**Screen storage case**  
Plastic container with transparent lid to store up to 2 different screens.



**Cleaning brush**  
To clean out any food or residue in the screens.

RPM (speed control setting) for use on the tilt-head and bowl-lift stand mixers Tolerance +/- 10%

	Stir	2	3	4	5	6	7	8	9	10
4.8 L tilt-head stand mixer	25	39	-	56	-	74	-	93	-	105
6.9 L bowl-lift stand mixer	20	25	37	46	55	65	72	82	93	100

\* Does not fit the professional bowl-lift stand mixer model 5KSM7990X.

**KitchenAid**