



Food and packages

Packaged food
Fruits
Vegetables
Milk packets



Electronics

Mobile phones
Remote
Laptops
Power banks



Retail outlets

Instruments
Currency notes
Bill books



Baby products

Toys
Bottles



Personal products

Keys
Hand bags
Watches
Combs
Sunglasses



Items that can be disinfected

Quick disinfection

Deactivates viruses in matter of few minutes

2 min

Small objects



3 min

Medium objects



5 min

Multiple medium objects



8 min

Large objects



Select time based on size and quantity of items to be disinfected

Philips UV-C Disinfection system is **safe to use**



Safety Mechanism

Auto cut off of UV-C radiation, when glass door is opened



Special glass door

Contains the UV-C radiation within the chamber




Safe for food and electronic items

Does not affect the quality of food or functioning of electronics. Only disinfects outer surface



How to use
Philips UV-C Disinfection system
Easy four step process



Turn on power supply. Once the digital display is lit, the product is turned on.



Open the door and place items to be disinfected above the grill.
Note: Maintain distance between the items. Do not stack items one above the other.



Set timer as per the quantity and size of items to be disinfected. Use one of the following modes for setting time.

1. Custom mode

Set timing of 2, 5 or 8 mins by pressing the buttons on the front panel.

Use (+) & (-) buttons to increase/decrease timer by 1 min.

Press start button to begin the disinfection process.

2. Quick/ Easy mode

Press start button twice to begin disinfection process with 3 mins timer.

Once the timer is completed, the UV-C light will turn off, completing the disinfection.

Open the door and take out your disinfected items.

